



NOTE: TIGHTEN TO APPROX.
100 in/lbs..

INSTRUCTIONS

- A. ASSEMBLE AS SHOWN
- B. LAMP HAS SEPERATE WIRE FOR GROUND (BLACK OR BROWN)
MAKE SURE THIS WIRE IS PROPERLY GROUNDED
- C. DRILL MOUNTING HOLE TO SUIT

PARTS LIST

- 1. 5/16 BOLT
- 2. 5/16 HEX LOCKNUT
- 3. U-BRACKET
- 4. 1" LONG CARRIAGE BOLT
- 5. VEHICLE MOUNTING SURFACE
- 6). LOCKWASHER
- 7. HEX NUT
- 8. EXTERNAL TOOTH WASHER (2)

NOTE: OPTIONAL REAR MOUNTING - SIMPLY REVERSE BRACKET ASSEMBLY.
NEW WIRE EXIT HOLE MUST BE DRILLED