

INSTALLATION INSTRUCTIONS

⚠ WARNING

To properly install this warning light you should have a good understanding of automotive electrical procedures and systems, and proficiency in the installation of warning lights. **IF YOU DO NOT, PLEASE SEEK PROFESSIONAL ASSISTANCE.**

BEFORE INSTALLATION:

- Estimated Time:** 20 minutes
- Tools Needed:** Needle Nose Pliers
- Wire Functions:** Black = Ground
Red = Power
- In the Box:**
1. Flat Edge Trim Ring
 2. Trim Ring
 3. Silver Snap Ring
- Input Voltage:** 12-24 V DC
- Operating Voltage:** 10-32 V DC

PRE-INSTALLATION INSTRUCTIONS:

1. Read all safety notes and mounting guidelines before installing the product. Verify that all parts listed under "In the Box" are present and complete.
2. Inspect the product for damage. DO NOT install the product if there is any damage. Contact the authorized retailer where you purchased it to initiate a warranty claim if there is damage.
3. Verify that all power supply and/or charging systems comply to the specified voltage limits for the light.

NOTES:

In using this guide, you agree J.W. Speaker is not responsible for any damage, misuse, or personal injuries. This document is intended as an educational guide only and does not make guarantees on any finished results.

To properly install this light you should have a good understanding of automotive electrical procedures and systems, and proficiency in the installation of lights. **IF YOU DO NOT, PLEASE SEEK PROFESSIONAL ASSISTANCE.**

⚠ **WARNING:** Cancer and Reproductive Harm - www.P65Warnings.ca.gov
 ⚠ **AVERTISSEMENT:** Cancer et effet nocif sur la reproduction - www.P65Warnings.ca.gov

PRODUCT WARRANTY:

If you have issues with a J.W. Speaker product, please contact the authorized retailer where you purchased it.



INSTALLATION INSTRUCTIONS:

1. Locate the camera inside the box. Locate the 2 different trim rings inside the camera bag. You need to use the flat edge trim ring circled in red.



5. Ensure the arrow (top of the camera) is facing up. Snap Camera into the bezel by applying pressure. This is important in ensuring the camera view is displayed correctly on the monitor.



2. Remove the clear film from the front of the camera.



6. Connect camera to monitor. AV1 connects to the driver's side light, and AV2 connects to the passenger's side light.



3. Place the metal snap on the camera. See picture for correct orientation of the snap.



7. Use the monitor to determine if the camera picture is centered or needs any adjustments. If no adjustments are needed, the camera installation is complete. If adjustments need to be made, please proceed to step 8.

8. Locate the 2 small holes on the back of the camera.



4. Screw the flat edge trim ring on the camera.



9. Insert the tips of the needle nose pliers into the 2 small holes on the back of the camera while it is **installed on the lamp**. Then turn only in the clockwise direction to aim the camera.

NOTE: Turn clockwise only.



10. Repeat step 7.