


DUAL HEADLIGHT WIRING INSTRUCTIONS

A WARNING



To properly install this headlight you should have a good understanding of automotive electrical procedures and systems, and proficiency in the installation of headlights. IF YOU DO NOT, PLEASE SEEK PROFESSIONAL ASSISTANCE.

INSTALLATION:



* Control line must be connected to power V₊ or Ground V₋ At powerup of lamp, **control line** *cannot* **be floating** (Not connected)!