

Model 8770S



Locomotive Headlight Wiring Instruction Sheet

PRE-INSTALLATION INFORMATION

Input Voltage

75V DC Nominal

To properly install this light you should have a good understanding of automotive electrical procedures and systems, and proficiency in the installation of headlights. IF YOU DO NOT, PLEASE SEEK PROFESSIONAL ASSISTANCE.


PRODUCT WARRANTY:

If you have issues with a J.W. Speaker product, please contact the authorized retailer where you purchased it.

Headlight Wiring

Rear Lamp Diagram

Auxiliary/Ditch Light Wiring Rear Lamp Diagram



Connect to VGND (-) = High Light Output