

Programming Your Model 255 Vehicle ID Sign

Before You Begin

The programming procedure for your sign has been designed to be an intuitive one button operation. However, it is important to keep a few things in mind.

1. Signs can only enter program mode at power up.
 2. The programming button **cannot** be held down at power up.
 3. After programming you must cycle power to complete the procedure.
-

Steps to Follow

1. Power up sign with programming switch attached, but not pressed.
 2. Within the first 10 seconds press and hold the programming button.
 3. When the first character starts to flash, release the button.
 4. Each momentary button press will increment the character.
 5. Press and hold the button to move to the next character.
 6. When all characters are at the desired value, power down the sign and remove the programming button.
 7. When the sign is powered back up, the display should be as programmed.
-

